



# Quick Start Guide


## POS80D




## Packing List




Printer




USB Cable



Power Cord



Serial Cable



Power Adapter



Roll Paper



CD




Quick Start Guide

Note:


- 1) The packing materials are actually dependent on the order.
- 2) The power adapter and power cord vary by local or region.

## Appearance and Components


### ■ Front



### ■ Rear




### ■ Inside




# Paper Installation (Forward Paper-out Direction)


1.Press the Cover Open Button.




2.In the correct direction of the roll paper,install the roll paper.



3.Pull out some roll paper, and close the printer cover.



4.Tear the extra paper in the direction of printer.



# Power Supply

- 1.Connect power adapter with printer.
- 2.Connect power adapter with power cord.
- 3.Plug the other side of power cord into the socket outlet.

